



NOTES

1. USE ECCENTRIC CONES. PLACE THE CONE ENTRY HOLE ABOVE THE OUTLET PIPE.
2. PROVIDE PRECAST BARREL SECTIONS AND CONES THAT MEET THE REQUIREMENTS OF THE CURRENT WASHINGTON DOT STANDARD SPECIFICATIONS. PRECAST BASE AND INVERT SECTIONS WITH INTEGRAL SEALS MAY BE USED.
3. A MINIMUM OF 8 INCHES OF WALL SHALL REMAIN BETWEEN HOLES.
4. ASSEMBLED MANHOLE STRUCTURE SHALL BE WATER TIGHT.